



replacement For AUDI

Audi 80 86-94



1A-7701-B

GRILLE
BLACK



1A-7701-C

GRILLE
ALL CHROMED



1A-7701-CB

GRILLE
CHROMED/BLACK



Audi A3 96-00



1A-7702-B

GRILLE
BLACK



1A-7702-C

GRILLE
ALL CHROMED



1A-7702-CB

GRILLE
CHROMED/BLACK



Audi A3 01-04



1A-7707-B

GRILLE
BLACK



1A-7707-C

GRILLE
ALL CHROMED



1A-7707-CB

GRILLE
CHROMED/BLACK



Audi A3 05-08



1A-7716-BA

GRILLE/RS LOOK
W/ LOGO BASE
W/BRACKET LICENSE PLATE
BRIGHT BLACK-BLACK



1A-7716-C

GRILLE/RS LOOK
W/ LOGO BASE
W/BRACKET LICENSE PLATE
ALL CHROMED



1A-7716-CB

GRILLE/RS LOOK
W/ LOGO BASE
W/BRACKET LICENSE PLATE
CHROMED BLACK





replacement For AUDI

Audi A3 05-09



1A-7709-CB

GRILLE
S8 LOOK
CHROMED/BLACK



1A-7709-BA

GRILLE
S8 LOOK
BRIGHT BLACK



Audi A3 09-11

1A-7714H-BA
1A-7714-BA

GRILLE/S8 LOOK
W/ SENSOR HOLE
(W/O SENSOR HOLE)
W LOGO BASE
BRIGHT BLACK



1A-7714H-CB
1A-7714-CB

GRILLE/S8 LOOK
W/ SENSOR HOLE
(W/O SENSOR HOLE)
W LOGO BASE
CHROMED BLACK



1A-7715H-BA
1A-7715-BA

GRILLE/RS LOOK
W/ SENSOR HOLE
(W/O SENSOR HOLE)
W LOGO BASE
W/BACKET LICENSE PLATE
BRIGHT BLACK-BLACK



1A-7715H-C
1A-7715-C

GRILLE/RS LOOK
W/ SENSOR HOLE
(W/O SENSOR HOLE)
W LOGO BASE
W/BACKET LICENSE PLATE
ALL CHROMED



1A-7715H-CB
1A-7715-CB

GRILLE/RS LOOK
W/ SENSOR HOLE
(W/O SENSOR HOLE)
W LOGO BASE
W/BACKET LICENSE PLATE
CHROMED BLACK





replacement For AUDI

Audi A4 96-00



1A-7703-B
GRILLE
BLACK



1A-7703-C
GRILLE
ALL CHROMED



1A-7703-CB
GRILLE
CHROMED/BLACK



Audi A4 01-05



1A-7705-B
GRILLE
BLACK



1A-7705-C
GRILLE
ALL CHROMED



1A-7705-CB
GRILLE
CHROMED/BLACK



Audi A4 05-08



1A-7710H-B
1A-7710-B
GRILLE/RS STYLE
W/ SENSOR HOLE
(W/O SENSOR HOLE)
BLACK



1A-7710H-C
1A-7710-C
GRILLE/RS STYLE
W/ SENSOR HOLE
(W/O SENSOR HOLE)
ALL CHROMED



1A-7710H-CB
1A-7710-CB
GRILLE/RS STYLE
W/ SENSOR HOLE
(W/O SENSOR HOLE)
CHROMED/BLACK



1A-7711H-CB
1A-7711-CB
GRILLE/S8 LOOK
W/ SENSOR HOLE
(W/O SENSOR HOLE)
CHROMED-BLACK



1A-7711H-BA
1A-7711-BA
GRILLE/S8 LOOK
W/ SENSOR HOLE
(W/O SENSOR HOLE)
BRIGHT-BLACK



1A-7711H-B
1A-7711-B
GRILLE/S8 LOOK
W/ SENSOR HOLE
(W/O SENSOR HOLE)
BLACK



**Audi A4** 05-08**1A-7711FRA-01**
1A-7711FRA-11

FR BUMPER/S8 LOOK
W/O SENSOR HOLE
(W/ SENSOR HOLE)
W/ H/L WASHER HOLE
W/ GRILLE(S8 STYLE)(BLACK)
W/ COVER WASHER NOZZLE
W/ FOG LAMP COVER
W/ FOG LAMP COVER BASE
W/ COVER TOW HOOK

**1A-7711FRB-01**
1A-7711FRB-11

FR BUMPER/S8 LOOK
W/O SENSOR HOLE
(W/ SENSOR HOLE)
W/ H/L WASHER HOLE
W/ GRILLE(S8 STYLE)(CHROMED BLACK)
W/ COVER WASHER NOZZLE
W/ FOG LAMP COVER
W/ FOG LAMP COVER BASE
W/ COVER TOW HOOK

**1A-7711FRC-01**
1A-7711FRC-11

FR BUMPER/S8 LOOK
W/O SENSOR HOLE
(W/ SENSOR HOLE)
W/ H/L WASHER HOLE
W/ GRILLE(S8 STYLE)(BRIGHT BLACK)
W/ COVER WASHER NOZZLE
W/ FOG LAMP COVER
W/ FOG LAMP COVER BASE
W/ COVER TOW HOOK

**1A-7711FRD-01**
1A-7711FRD-11

FR BUMPER/RSLOOK
W/O SENSOR HOLE
(W/ SENSOR HOLE)
W/ H/L WASHER HOLE
W/ GRILLE(BLACK)
W/ COVER WASHER NOZZLE
W/ FOG LAMP COVER
W/ FOG LAMP COVER BASE
W/ COVER TOW HOOK





replacement For AUDI

Audi A4 05-08



1A-7711FRE-01
1A-7711FRE-11

FR BUMPER/RS LOOK
W/O SENSOR HOLE
(W/ SENSOR HOLE)
W/ H/L WASHER HOLE
W/ GRILLE(CHROMED BLACK)
W/ COVER WASHER NOZZLE
W/ FOG LAMP COVER
W/ FOG LAMP COVER BASE
W/ COVER TOW HOOK



Audi A6 97



1A-7706-B

GRILLE
BLACK

1A-7706-C

GRILLE
ALL CHROMED

1A-7706-CB

GRILLE
CHROMED/BLACK



Audi A6 04-07



1A-7704-B

GRILLE
BLACK

1A-7704-C

GRILLE
ALL CHROMED

1A-7704-CB

GRILLE
CHROMED/BLACK





replacement For AUDI

Audi S4 05-08



1A-7708-C
GRILLE/RS STYLE
W/O P.D.C
ALL CHROMED



1A-7708-BA
GRILLE/RS STYLE
W/O P.D.C
BRIGHT BLACK



1A-7708-CB
GRILLE/RS STYLE
W/O P.D.C
CHROMED BLACK



1A-7712-BA
GRILLE/S8 STYLE
W/O P.D.C
BLACK



1A-7712-CB
GRILLE/S8 STYLE
W/O P.D.C
CHROMED BLACK



Audi TT 98-06



1A-7713-B
GRILLE
BLACK

